

Patio Panel Door

1. Measure the opening that you wish to cover with the screen.
2. Cut the top rod to the required length if necessary.
3. Separate the central top rod tube, from the half round one. Simply overlap the two panels of material. Now push the tube in place, starting at one end of the rod and working towards the other.
4. Put the top rod in position either with the supplied hook and loop tape, or with the supplied self tapping screws, see instructions below.
5. To mount the top rod with screws. (i) Cut rod to size. (ii) Measure and mark the middle of the tube and then measure about 10cm in from each end.
6. Drill a hole slightly bigger than the rounded self-tapping screw head supplied into the tube, not the half round piece.
7. Position the three screws at the measurements above your doorway. Push the rod onto the screws.



8. Use the hook and loop tape to secure either side of the screen, or if it is wood use the supplied tacks.
9. Attach the other tubular rod to act as the weight. If necessary cut to rod to the same length as the top rod. You can either leave it as a complete length or cut it to the length of the panel to make an overlapping entrance.
10. Clip the bottom rod into position and once you are happy how the screen hangs then cut off the excess material.

Patio Panel Door

1. Measure the opening that you wish to cover with the screen.
2. Cut the top rod to the required length if necessary.
3. Separate the central top rod tube, from the half round one. Simply overlap the two panels of material. Now push the tube in place, starting at one end of the rod and working towards the other.
4. Put the top rod in position either with the supplied hook and loop tape, or with the supplied self tapping screws, see instructions below.
5. To mount the top rod with screws. (i) Cut rod to size. (ii) Measure and mark the middle of the tube and then measure about 10cm in from each end.
6. Drill a hole slightly bigger than the rounded self-tapping screw head supplied into the tube, not the half round piece.
7. Position the three screws at the measurements above your doorway. Push the rod onto the screws.



8. Use the hook and loop tape to secure either side of the screen, or if it is wood use the supplied tacks.
9. Attach the other tubular rod to act as the weight. If necessary cut to rod to the same length as the top rod. You can either leave it as a complete length or cut it to the length of the panel to make an overlapping entrance.
10. Clip the bottom rod into position and once you are happy how the screen hangs then cut off the excess material.