

Multi Panel Plus Fitting Instructions

1. Measure the width of the door frame that you want to cover.
2. Either cut the top rod to the required width, or leave it if you are happy for an overlap.
3. Separate the small dowel at the back of the top rod.
4. Measure the height of the doorway, or where you want the rod to be.
5. Mark this measurement on each panel.
6. Lay the panels on the floor over the top rod and push the dowel into the top rod trapping the panels working from the middle outwards to each end.
7. Hold the top rod in place. It is unlikely you will get the overlaps and drop perfect first time! It will take patience.
8. Only once you are happy with the way the screen looks then either screw in place (use the supplied screw collar and then press on the cover) or use the supplied adhesive fixings.
9. Leave the screen in place and only when you are satisfied with the overlaps and the way it touches the ground, cut the excess material at the top.

