

MAGNETIC DOOR INSTRUCTIONS

Once you are happy with the height and the position on either side of the frame then use one piece of self adhesive tape at the top and then spread out the rest of the Tape on each side of the door frame. On a wooden door frame you can also use pin tacks. It is also possible to use wooden battens. The optional top rod also makes it more secure if there are pets/children.

