



1. Measure your window opening. Allow for an overlap of at least 15mm-20mm all the way around the frame to make fitting easier.
2. Cut the four lengths of the plastic frame with scissors, or similar.
3. Insert the frame lengths into the corners to make the window frame.
4. Now overlay the flyscreen material and don't forget to insert the pull handle into the corners where you want to pull your frame away from the window to open or close it.
5. Press the magnetic strip firmly into the groove, cut the magnet length with strong scissors, to hold the material in place.
6. Once you have finished the frame and are happy, cut off excess flyscreen material.
7. Let the flat magnet attach itself to the frame. Peel off the protective strip on the flat magnet and apply the whole frame to the window. This is the best way ensure that the magnets line up perfectly.
8. Optionally you can place the two self-adhesive metal clips at either end of the top of the frame for extra protection against high winds.
9. Lift protective film on the sides to about 1/3rd of the length and place the holding clips in with the adhesive sides up.
10. Clean the window frame thoroughly and let it dry.
11. Mount the screen to the window by peeling off the protective film. Press it until it feels firm.
12. Ideally leave the screen in position for at least 12 hours before lifting the screen.

