

Windows Plus Fitting Instructions ¶

¶ Ensure that the window frames are free of dust and grease, so please clean them thoroughly. Also if the frames have polish on them make sure this is removed before attempting to apply the Hook tape ¶

- ¶ 1. Apply the adhesive Hook tape around the window frame. ¶
- ¶ 2. Measure the width and length and cut the screen material to fit with a sharp knife or... ¶
- ¶ 3. Put the material onto the window frame and then cut to size with scissors. ¶
- ¶ 4. Open window. ¶
- ¶ 5. Apply screen material to the Hook tape by dragging a blunt instrument down the side. You must hear the hook tape grab the material. It will not work by pressing the material. ¶
- ¶ 6. Relax and enjoy a bug free, fresh air life style thanks to the Flyscreen Queen ¶

