

Commercial Flyscreen Frame



What you Get • Profiles x 4 • Rubber Spline • Spline Pusher tool • Brush Strip • Grey Flyscreen Material • Corners x 4 **You will need:** Large Rubber Mallet • Hacksaw/Mitre Box or Mitre Saw

1. Measure the door frame and allow for a small overlap at least a 1cm.
2. Cut profiles to the height required minus measurement of the corners (53mm).
3. Cut profiles to the width required minus the measurement of the corners (53mm)
4. Slide brush into the top and bottom of profiles then insert corners with the mallet. Ensure that the corner is the right way around and has the pin in each corner on the same side as the groove in the profile.
5. Slide brush into the Side Profiles, cut off the excess and push on the completed top and bottom profiles.
6. Lay the mesh over the door. Use the pusher Tool to insert the rubber spline into the groove which holds the mesh in place. The best tip is to put spline in one side then the other side directly opposite, this helps pull it taut.
7. Once the mesh is in place, cut off the excess material with a craft knife that you can just run along the outside of the spline.

